INSTALLATION INSTRUCTIONS

WARNING: On vehicles equipped with airbags or supplemental inflatable restraint systems, refer to the vehicle's service manual for airbag disarming procedures before performing repairs. Serious injury or death may occur as a result of accidental airbag deployment

Remove or disconnect the following:

1. Negative battery cable.
2. Two screws from the lower column shroud.
3. Lower column shroud by tilting shroud down and sliding rearward to disengage locking tabs.
4. Two screws from upper column shroud.
5. Lift upper column shroud to gain access to lock cylinder removal hole.
6. Hold key in "START" position and use a 1/16-inch hex wrench to push on the lock cylinder-retaining pin.
7. Release the key to "RUN" position and pull lock cylinder from the lock cylinder housing.

Reverse procedure to install, noting the following:

- Two screws to upper shroud. Tighten to 12-inch lbs.
- Two screws to lower shroud. Tighten to 53-inch lbs.

Notice:

This lock cylinder is a Vehicle Theft Deterrent System component. When this cylinder or any other part of the system is replaced, it requires a relearn procedure. This may include clearing previous codes from the Body Control System with a suitable scan tool and other procedures to initialize the new component. Please refer to the vehicle's Service Information for the specific procedure.