

Determining the correct upper front strut mount for your 2000-2005 Toyota Echo prior to removing it from the vehicle.

1. Please observe all safety considerations and wear the appropriate safety apparel before starting.
2. Find length "C" [See below diagram] on your existing mount, from center of the strut stud "A" to the center of the forward mounting bolt "B". You do not need to remove the mount from the vehicle to measure.

Note 1: You may need to remove a small plastic cap to expose the strut stud.
Note 2: Construction of mount may differ slightly from image.

Please purchase the following part based on the measurement:

Measurement C	Part Number
68mm (2.7in)	143194
56mm (2.2in)	143195

