



200-581 INSTALLATION INSTRUCTIONS 87-93 S-10 4.3L TBI

Thank you for purchasing the PowerAid Throttle Body Spacer. Please read the instruction manual carefully before proceeding with the installation. Contact AirAid @ (800) 498-6951 8:00 AM - 5:00 PM MST Weekdays for questions regarding fit or instructions that are not clear to you. Your PowerAid Throttle Body Spacer was carefully inspected and packaged. Check that no parts are missing, or were damaged during shipping. If any parts are missing, please contact AirAid.

Thank you for selecting AirAid.



Ask about our AirAid Intake System for your vehicle. Call for details!

Parts List

- (1) Power Plate
- (2) Gaskets
- (2) Drilled & Taped Bolts
- (1) Plain Bolt
- (3) 8mm Flat Washers

Tools List

- 1/2" Socket
- Standard Screwdriver

Installation Instructions. Read Me!

1. **DISCONNECT NEGATIVE (-) BATTERY CABLE.**
2. Remove air cleaner.
3. Using 1/2" socket, remove (3) 5/16" bolts.
 - * **Please Note: Some units have bolts that are drilled and taped for air cleaner mounting studs.**
4. It is not necessary to remove the fuel lines.
5. Remove fuel line bracket from transmission. (Located on drivers side of bell housing)
6. Lift throttle body unit.
7. Remove gasket and clean surfaces.
8. Install power plate using (2) gaskets.
 - A. Locate first gasket between TBI unit and power plate.
 - B. Locate second gasket between power plate and manifold.
9. Install power plate using (2) drilled and taped bolts, (1) plain bolt, and 3 8mm flat washers. **Refer to Step 3**
10. Replace air cleaner studs if applicable.
11. Inspect & Test throttle linkage for full Open & Closed travel before driving. Some cruise or kickdown cables may require adjustment. Please refer to your vehicles service manual for proper adjusting.
12. Reinstall the air cleaner.
13. Reinstall fuel line bracket. **Refer to Step 5**
14. Reconnect battery cable. Enjoy!

The sound of power...The "whistle" means its working!

