



200-589 INSTALLATION INSTRUCTIONS 1999-01 Chevy S-10/GMC S-15 2.2L

Thank you for purchasing the PowerAid Throttle Body Spacer. Please read the instruction manual carefully before proceeding with the installation. Contact AIRAID @ (800) 498-6951 8:00 AM - 5:00 PM MST Weekdays for questions regarding fit or instructions that are not clear to you. Your PowerAid Throttle Body Spacer was carefully inspected and packaged. Check that no parts are missing, or were damaged during shipping. If any parts are missing, please contact AIRAID.

Thank you for selecting AIRAID.



Parts List

- (1) Power Plate
- (1) "O" Ring
- (1) Extension Plate
- (1) Flat Head Screw 6mm x 20mm
- (1) Bolt 6mm x 25mm
- (1) Flat Washer 6mm
- (2) Bolts 6mm x 57mm
- (2) Bolts 6mm x 76mm

Tools List

- 10mm Socket
- 5/32" Allen Wrench
- Flat Head Screwdriver

Installation Instructions. Read Me!

1. DISCONNECT NEGATIVE (-) BATTERY CABLE.

2. Remove throttle body air intake system.
3. Remove bolts, nuts, and studs from throttle body and manifold (**Ref. "B"**).
4. Install power plate using (4) 6mm bolts (**Ref. "B"**).
5. Install (1) extension plate using (1) 6mm flat head screw (**Ref. "C"**).
6. Inspect & Test throttle linkage for full open & closed travel before driving. Some cruise or kick-down cables may require adjustment. Refer to service manual for proper adjustment.
7. Reinstall air intake system using (**Step 2**) as an example.
 - * **Note:** Use furnished 6mm x 25mm bolt & 6mm washer for air box support.
8. Reconnect battery cable. Enjoy!

The sound of power...The "whistle" means its working!

Extension Plate

Flat Head Screw 6mm x 20mm

Bolt 6mm x 25mm (Air box Support)

Ref. C- Flat Washer 6mm (Air box Support)



Ref. A- Power Plate
"O" Ring

Ref. B- Bolts 6mm x 76mm (Top)
Bolts 6mm x 57mm (Bottom)