



510-537 INSTALLATION INSTRUCTIONS 2003-04 Toyota Tundra 4.7L 2004 Toyota 4Runner 4.7L

Thank you for purchasing the PowerAid Throttle Body Spacer. Please read the instruction manual carefully before proceeding with the installation. Contact AIRAID @ (800) 498-6951 8:00 AM - 5:00 PM MST Weekdays for questions regarding fit or instructions that are not clear to you. Your PowerAid Throttle Body Spacer was carefully inspected and packaged. Check that no parts are missing, or were damaged during shipping. If any parts are missing, please contact AIRAID.

Thank you for selecting AIRAID.



Parts List

- (1) Power Plate
- (3) "O"- Rings
- (4) 8mm x 100mm Hex Bolts
- (4) 8mm Flat Washers

Tools List

10mm Socket

Installation Instructions. Read Me!

1. **DISCONNECT NEGATIVE (-) BATTERY CABLE.**
2. Remove air intake hose assembly.
3. Remove throttle body cover and save nuts.
4. Remove throttle body bolts, nuts, and studs.
5. Remove throttle body and install power plate using (3) "O" Rings, (4) 8mm x 100mm hex bolts, and (4) 8mm flat washers. (Ref. "A", "B")
6. Inspect & Test throttle linkage for full Open & Closed travel before driving. Some cruise or kickdown cables may require adjustment. Please refer to your vehicles service manual for proper adjustment.
7. Reinstall throttle body cover using saved nuts and air intake hose. (Ref. to Steps 2 & 3)
8. Reconnect negative battery cable. Enjoy!

The sound of power...The "whistle" means its working!

Ref. "A"- (1) Power Plate
(3) "O"-Rings



Ref. "B"- (4) 8mm x 100mm Hex Bolts
(4) 8mm Flat Washers