

Installation Instructions **5.5151**
2000-JAN/01 Mitsubishi Eclipse



1131 VIA CALLEJON, SAN CLEMENTE, CA

It is recommended that if you are unfamiliar with this type of work that you refer to a qualified service center specializing in this type of work. It is also recommended that if you choose to do this work yourself that a factory service manual be obtained for the proper procedures pertaining to removal, replacement and proper torque specifications for your vehicle. This instruction set is intended as a guideline for the safe installation of Energy Suspension's Polyurethane.

The installation of this sway bar bushing set will require the removal of both left and right lower control arms.




Loosen and remove the forward pivot bolt on the lower control arm.

Loosen and remove the two vertical bolts that attach the rear bushing pivot assembly. Do this on both left and right control arms.

Loosen and remove the two bolts that attach the sway bar bushing retaining plate. Do this on both sides and lower bar out of position.

Remove old bushing.

Clean thoroughly the bushing surface and apply a liberal amount of the supplied grease. Install bushing onto bar and install in reverse order of removal.



© 2005 Energy Suspension. All rights reserved.
May not be reproduced, in any form, or by any means,
without the written consent of Energy Suspension.

17378

082702PS
Updated 15/FEB/05 BRH