



**Application: Application: Aplicación:**

Audi 90, A4, S4, Cabriolet, Quattro A4, 90 | Volkswagen Passat



*Please use caution when installing and refer to both IB12 and IB12A to determine correct installation instruction for the vehicle.*

**Location of cabin filter:**

In front of the windshield under the cowl trim on the passenger side of the vehicle.

**Tools:**

Unknown or not required.

**To remove existing filter:**

1. Remove the passenger side of the cowl trim (the cowl trim is split down the middle).
2. Remove one screw and three catches.
3. Remove drip rail by pulling to the front.
4. Remove filter from the housing.
5. Reverse procedure to install new filter.

*Note: Drip rail must be mounted properly, otherwise rain will run into filter and heater.*