

Difficulty Rating
Note de difficulté
Calificación de dificultad



Installation Bulletin | Bulletin d'installation | Boletín de Instalación

CAF1707/CAF7707

08-08

Application: Application: Aplicación:

Cadillac Escalade | Chevrolet Silverado, Suburban, C3500, Avalanche, Tahoe | GMC Sierra, Yukon, Denali



Location of cabin filter:

Under passenger side dash remove hush panel and behind access door.

Tools:

7mm & 9mm Socket

To remove existing filter:

1. Locate and remove the hush panel (if equipped) under the passenger side dash panel.
2. After removal of the hush panel locate the filter access door.
3. Unclip the filter access door from the front of the housing.
4. Pivot door to the side to provide access to the filters.
5. Remove the front filter by pulling downward.
6. Slide the rear filter forward and remove by pulling downward.
7. Reverse the procedure to install the new filters.