



Application: Application: Aplicación:

Nissan Pathfinder, Altima | Infiniti G20, QX4



*Caution or service label will be on glove box door if vehicle is equipped with cabin filter.*

**Location of filter:**

On the passenger side of the vehicle behind the glove compartment.

**To remove existing filter:**

1. With glove compartment closed locate and remove the two screws at the bottom of the glove compartment securing the glove compartment frame to the dash panel.
2. Open the glove compartment and locate and remove the four screws at the top of the glove compartment securing the glove compartment frame to the dash panel.
3. Remove the glove compartment and assembly.
4. Locate and remove the screw securing the cabin filter cover and then remove the cover.
5. Remove the dirty cabin filters.
6. Replace the dirty filters by inserting the first clean filter in the housing and sliding to the right.
7. Insert the second filter in the housing and secure the cabin filter cover and screw.
8. To complete installation reverse steps 1-3.