

Difficulty Rating
Note de difficulté
Calificación de dificultad



Installation Bulletin | Bulletin d'installation | Boletín de Instalación

CAF1732/CAF7732 02-09

Application: Application: Aplicación:

Porsche Cayenne and VW Tourage



Location of filter:

On passenger side foot well

Tools:

Phillips Screwdriver

To remove existing filter:

1. Locate and remove the trim on the passenger side foot well.
2. Locate and remove the screws on either side of the cabin filter cover and remove cover.
3. Pull downward on dirt filter and remove.
4. Replace with clean filter.
5. Complete installation by reversing steps 1-2.