



Application: Application: Aplicación:

Buick Park Avenue | Cadillac Seville



Location of cabin filter:

In front of the windshield under filter access cover on the passenger side of the vehicle.

Tools:

Unknown or not required.

To remove existing filter:

1. Release and open hood.
2. Remove cabin filter cover from along cowl vent screen on the passenger side of the vehicle. (Fig. 1)
3. Remove filter by lifting straight up. Then pull straight out through access door. (Fig. 2.)
4. When inserting new cabin filter into filter cavity, make sure that the edge with the foam rubber seal is facing down as shown in detail view. (Fig 3.)
5. After cabin filter is placed into filter housing, gently press down on filter to insure that the seal is seated properly in filter housing. (Fig. 4)
6. Reverse steps 1-5 to complete installation.

