

Difficulty Rating
Note de difficulté
Calificación de dificultad



Installation Bulletin **CAF1765**

Bulletin d'installation
Boletín de Instalación

08-08

Application: Application: Aplicación:

Pontiac Vibe | Toyota Tacoma



Location of cabin filter:

Behind the glove compartment behind an access door on the passenger side of the vehicle

To remove existing filter:

1. Open the glove compartment and push in on the sides of the glove compartment and rotate glove compartment down.
2. Locate the cabin filter access door.
3. Remove the filter access door by lifting up on the two levers on the top edge of the cover.
4. Remove the existing dirty filter.
5. Install new filter.
6. Reattach the filter access door.
7. Rotate glove compartment back into place by depressing in on sides and closing the compartment