

TB #001

## GM V-5 & V-7 COMPRESSORS

**MUST ADD OIL TO CRANKCASE**

This compressor has been shipped dry.

Add 2.0 – 3.0 ounces of PAG oil to the compressor thru the crankcase drain bolt prior to installation. Add the balance of the oil charge to the accumulator dehydrator or the receiver dryer.

