

# EZ-SENSOR® MUST BE PROGRAMMED BY A TECHNICIAN BEFORE INSTALLING

## IT'S EZ TO PROGRAM!

1. Check the catalog for the correct sensor to use. If EZ-sensor is available for the vehicle, choose the correct EZ-sensor from stock.
2. From the home screen, choose **PROGRAM SENSOR**.
3. Choose the correct **MAKE, MODEL, YEAR**.
4. Choose **SCHRADER EZ-SENSOR**.  
**Note: If 'EZ-SENSOR' does not appear on the list of sensor options, you cannot use an EZ-sensor. Check the Application Guide for the correct replacement sensor part number.**
5. Select **PROGRAM SENSOR** or **PROG**.
6. Select Wheel Position.
7. Select **CREATE ID** or **COPY ID**.
8. Place appropriate EZ-sensor in front of tool, press **ENTER**.
9. Wait for the tool to respond **PROGRAM SUCCESSFUL**.
10. The new EZ-sensor is ready to be installed and you MUST complete a relearn on the vehicle.

**EZ-SENSOR CAN BE RE-PROGRAMMED IF NEEDED**

