

Primary .5 - 1.1
Secondary Cannot Read
Physical Inspection

1. Check for corrosion on terminals
2. Check for cracks or carbon tracking

