

# Part # C960

## Primary .4 - 1.0 Secondary Cannot Read Physical Inspection

1. Check for corrosion on terminals
2. Check for cracks or carbon tracking

