

Starter No Crank

1996 Jeep Cherokee

Condition: Erratic operation of any electrical circuit fed through the Power Distribution Circuit (PDC). This may include: Vehicle will not crank, lights flickering on and off, inoperative accessories.

Cause: Main fuse power - Design issue. Chrysler recommends replacing the *Mega Fuse* with a fusible link. The *Mega Fuse* is located at the Power Distribution Center, which is on the passenger side of the engine compartment near the battery and engine coolant reservoir. See Chrysler TSB 08-41-95 for further information.

