

CONTROL MODULE DR148 (A)

©2009 WELLS Manufacturing, L.P.
All Rights Reserved. No portion of this manual may be reproduced without the written permission of Wells Manufacturing, L.P.

NOTES

1



If "SH" displays, check connections and retest. If there is no change, the module has failed.

2

Do not allow clips to touch each other or module housing. If this occurs, the module may be misdiagnosed.


3

**FOR ASSISTANCE CALL:
WELLS MANUFACTURING, L.P.
1-800-558-9770
FOR CUSTOMER SERVICE**

STEP 1: FIND CORRECT LEAD WIRE



STEP 3: CONNECT TO TESTER




STEP 4: SETTING UP TESTER

Enter product select number "13" and press start to begin test.



STEP 2: MAKE CONNECTIONS TO PART (DR148)



DANGER: Do not handle the module during or immediately after the test sequence, as electrical shocks and burns may occur.




Yellow

Green

Blue

**Connector
Side**



3 Blue Common Wires

