


CONTROL MODULE F121 (A)

©2009 WELLS Manufacturing, L.P.
All Rights Reserved. No portion of this manual may be reproduced without the written permission of Wells Manufacturing, L.P.

NOTES

1




If "SH" displays, check connections and retest. If there is no change, the module has failed.

2


3

**FOR ASSISTANCE CALL:
WELLS MANUFACTURING, L.P.
1-800-558-9770
FOR CUSTOMER SERVICE**

STEP 1: FIND CORRECT LEAD WIRE



STEP 3: CONNECT TO TESTER




STEP 4: SETTING UP TESTER

Enter product select number "04" and press start to begin test.



STEP 2: MAKE CONNECTIONS TO PART (F121)



DANGER: Do not handle the module during or immediately after the test sequence, as electrical shocks and burns may occur.

Input Signal Reference- Ground


Ignition Coil Negative

Run- Battery Positive Through
Ignition Switch

Start Terminal

Input Signal Positive- Program
Line For Spark Output


Hall Sensor Output



Hall Sensor Positive Input

Hall Sensor Voltage Positive

Battery Negative- Ground



WHEELS
ENGINE MANAGEMENT