

NOTES

1

SH


If "SH" displays, check connections and retest. If there is no change, the module has failed.

2


3

FOR ASSISTANCE CALL:
WELLS MANUFACTURING, L.P.
1-800-558-9770
FOR CUSTOMER SERVICE

STEP 1: FIND CORRECT LEAD WIRE



STEP 3: CONNECT TO TESTER




STEP 4: SETTING UP TESTER


Enter product select number "12" and press start to begin test.

12

STEP 2: MAKE CONNECTIONS TO PART (DR145)



DANGER: Do not handle the module during or immediately after the test sequence, as electrical shocks and burns may occur.



B- Battery Positive




A- Ground

A- YEL- 7X Positive

B- Not Used

C- PPL- 7X Ground



A- TAN/BLK- Bypass

B- WHT- EST

C- WHT- Tach Signal

D- Not Used

E- PPL/WHT 3x Reference

F- BLK/RED Ground